



BENEDICT

BENEDICT

Benedict Sands – Sandy Point Traffic Management Map

Direction of Travel



Stop Point



Speed Limit



Note: All company vehicles/contractor vehicles and mobile plant are to have an operational flashing beacon when commuting around site.

Employee vehicles entering/exiting site are to commute directly to car park/exit areas only. Employee vehicles are not required to have an operational flashing beacon.

All mobile plant are to have reversing/tracking beepers fitted and operational.

RMS seatbelt & mobile phone rules apply on site when driving a passenger/heavy vehicle on site.

Mobile phones are not to be used when operating mobile plant.

All planned mobile plant maintenance works is to be performed in the compound or another isolated area.

Any mobile maintenance works in quarry areas are to be segregated away from high traffic and production areas.

Vehicles associated with fixed plant maintenance are to park vehicles away from high traffic / production routes.

Seatbelts are to be worn at all times when operating mobile plant.

Heathcote Rd